

M O D E L 2500E

## 500 LBF ELECTRODYNAMIC EXCITER

- Forced air cooling sufficient to meet full shaker performance (500 lbf / 2.2 kN) specifications
- Large 6 in (152 mm) specimen mounting table offers ease of mounting
- 1.0 in (25.4 mm) stroke and wide frequency range (to 4500 Hz) support broad range of applications
- Trunnion base provides flexibility when choosing best exciter location
- Low stray magnetic field, minimized by built-in degauss coil

## **APPLICATIONS**

- Vibration testing of
  - Avionics
  - CubeSat Satellites
  - Consumer products
  - Automotive parts, electronics
  - Mechanical subassemblies

## **VERSATILE VIBRATION TESTING**

The Modal Shop's Electrodynamic Shaker Model 2500E is a 500 lbf pk sine force shaker designed for general-purpose vibration testing of small components, as well as stress screening of electronic and mechanical sub-assemblies. It is designed to re-create field vibration in a controlled laboratory setting and can be used in a variety of R&D, reliability, and quality assurance applications within the automotive, aerospace & defense, and consumer electronics sectors.

Model 2500E offers a large 6 in (152 mm) diameter specimen mounting table, making it easy to adapt to almost any test requirement with a minimum of fixturing. The table provides multiple internally threaded attachment points, making the shaker assembly ideally suited for applications such as production screening, reliability acceptance testing, and product engineering evaluation. The composite materials used for the armature suspension and guidance system provide a high degree of lateral and rotational restraint while maintaining maximum compliance in the axis of motion to permit full 1.0 in (25 mm) peak to peak stroke. The shaker and trunnion base assembly allow a variety of operating positions ranging from a standard vertical orientation to a rotation of 90° to interface with horizontal tables.


Model 2500E has an inherently low stray magnetic field, which is minimized even further by the use of a built-in degauss coil. Safety features include over travel switch protection, air-cooling flow interlocks, and safe start in mute mode associated with the Model 2050E12-7 Digital Power Amplifier. Optional accessories are available such as special vibration isolation mounts, metric inserts for specimen mounting, and a magnesium head expander.

SPECIFICATIONS		
Performance		
Output Force, sine pk, forced air cooling		500 lbf (2.2 kN) [1]
Output Force, random RMS, forced air cooling		350 lbf (1.6 kN) <sup>[1]</sup>
Output Force, shock pk		1000 lbf (4.4 kN) [1]
Stroke Length, continuous pk-pk		1.0 in (25.4 mm)
Stroke Length, between stops		1.2 in (30.5 mm)
Frequency Range, nominal		DC – 4500 Hz <sup>[2]</sup>
Fundamental Resonance		> 3300 Hz <sup>[2]</sup>
Maximum Velocity		140 in/s pk (356 cm/s pk)
Maximum Acceleration, bare table		100 g pk
Maximum Acceleration, resonance		150 g pk
Maximum Acceleration, pulse shock		300 g pk
Physical		
Platform Mounting Thread		5x 1/4-20 [3]
Armature Weight		5 lb (2.268 kg)
Suspension Stiffness (nominal)		250 lbf/in (43.8 N/mm)
Rated Drive Current, forced air cooling		40 A RMS
Stray Magnetic Field, 3.0 in (76.2 mm) above table		< 10 Gauss <sup>[4]</sup>
Stray Magnetic Field, 2.0 in (50.8 mm) from body		< 15 Gauss
Cooling Air		Air-cooled by suction type remote centrifugal blower with 12 ft. long flexible duct
Dimensions (H x W x D), nominal		21.0 x 14.5 x 14.0 in (533 x 368 x 356 mm) [5]
Weight, with trunnion		475 lb (215 kg)
Temperature Operating Range		40 – 100 °F (4 – 38 °C), < 85% RH
Field Supply		1 kW nominal
Supplied Accessories		
Trunnion Base, 3/8 in Hex Wrench, 10 ft (3 m) Shaker Cable		
Required Accessories (K2500E500 Shaker System)		
2050E12-7	Power A	mplifier, 3500 VA, field power supply, 200-240V, single phase
2000X12		Cooling Package
Optional Accessories		
Magnesium Head Expander 12 x 12 in (305 x 305 mm)		
Special Vibration Base Isolation Mounts (Solid 10 Hz, or Pneumatic 5 Hz)		

- [1] Full force range requires forced air cooling with 2050E12-7 power amplifier. [2] Load dependent, stated specifications based upon bare table.
- [3] Inserts also available with M6 x 1 threads.
- [4] Field adjustable with degaussing coil.
- [5] Reference outline drawing for details


Front Left Photo Courtesy of Cal Poly CubeSat Laboratory





## Model 2500E - Top View

Dimensions in inches



Model 2500E - Front View

Dimensions in inches



10310 Aerohub Boulevard, Cincinnati, OH 45215 USA

modalshop.com | info@modalshop.com | 800 860 4867 | +1 513 351 9919